



A - Lower Accumulator Sensor (Emitter) (3 used)  
B - Upper Accumulator Sensor (Emitter)  
C - Accumulator Position Switch  
D - Lower Accumulator Sensor (Receiver) (3 used)  
E - Unit Reduction Gearcase Speed Sensor (2 used)  
F - Row Sense Crop Sensor  
G - Fan Speed Sensor  
H - RMB Lock-Unlock Switches  
I - Gate Latch Switch  
J - Handler Position Sensor  
K - Front Bale On Handler Sensor (Emitter)  
L - Gate in Handler Switch  
M - Rear Bale On Handler Sensor (Emitter)

